

KINCROME

PROFESSIONAL QUALITY TOOLS

INDUSTRIAL AIR HYDRAULIC RIVETER 1/4" (6.4MM)

2
YEAR
WARRANTY

SUITABLE FOR
STAINLESS
STEEL,
ALUMINIUM
& STEEL RIVETS

6
NOSE
PIECES

1894KG
OF TRACTION
POWER



K13271


ED1 April 17

Table of Contents

Know Your Product 1
 General Safety Instructions 2-3
 Additional Safety Instructions 3
 Assembly 4-5
 Operation 5-6
 Maintenance & Warranty 6-7
 Parts Breakdown 7-8

Know your product

- 1. Air Inlet
- 2. Trigger
- 3. Nose Pieces (6.4mm, 5.6mm, 4.8mm, 4.0mm, 3.2mm, 2.4mm)
- 4. Frame Head
- 5. Frame Cap Nut
- 6. Frame Cap
- 7. Cylinder
- 8. Lock Nut
- 9a. Riveter Ring Spanner
- 9b. Riveter Nose Piece Spanner
- 9c. Riveter Open End Spanner
- 10. Jaw Spanner
- 11. Nitto Style Fitting
- 12a. Small Front Jaw Case
- 12b. Small Jaws (2.4mm & 3.2mm Rivets)
- 12c. Small Jaw Pusher
- 13a. Large Front Jaw Case
- 13b. Large Jaws (4.0mm, 4.8mm, 5.6mm & 6.4mm Rivets)
- 13c. Large Jaw Pusher
- 14. Rear Jaw Case



| | |
|---|----------------------------------|
| Model No: | K13271 |
| Description: | Industrial Air Hydraulic Riveter |
| Air Inlet: | 1/4" |
| Average Air Consumption: | 119 lpm |
| Number Of Jaws: | 2 Sets |
| Traction Power: | 1894kg (4166lb) |
| Inlet Air Pressure (max.): | 70-90 PSI |
| Hose Length (max.): | 10 meters |
| Hose Diameter (min.): | 10mm I.D (3/8") |
| Tool Length: | 232mm |
| Weight: | 2.05kg |

General Safety Warnings



Save all warnings and instructions for future reference.

WARNING! Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

1) Work Area

- a. **Keep the work area clean and well lit.** Cluttered benches and dark areas increase the risks of electric shock, fire, and injury to persons.
- b. **Keep bystanders, children, and visitors away while operating the tool.** Distractions can result in the loss of control of the tool.
- c. **Keep children and bystanders away while operating any powered products.** Distractions can cause you to lose control.

2) Personal Safety

- a. **Stay alert. Watch what you are doing and use common sense when operating the tool.** Do not use the tool while tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating the tool increases the risk of injury to persons.
- b. **Dress properly. Do not wear loose clothing or jewellery.** Contain long hair. Keep hair, clothing, and gloves away from moving parts. Loose clothes, jewellery, or long hair increases the risk of injury to persons as a result of being caught in moving parts.
- c. **Avoid unintentional starting.** Be sure the trigger is not depressed before connecting to the air supply. Do not carry the tool with your finger on the trigger or connect the tool to the air supply with the trigger on.
- d. **Remove adjusting keys and wrenches before turning the tool on.** A wrench or a key that is left attached to a rotating part of the tool increases the risk of personal injury.
- e. **Do not overreach.** Keep proper footing and balance at all times. Proper footing and balance enables better control of the tool in unexpected situations.
- f. **Use safety equipment.** A dust mask, non-skid safety shoes and a hard hat must be used for the applicable conditions. Wear heavy-duty work gloves during use.
- g. **Use eye and hearing protection.** Wear ANSI approved safety impact goggles, hearing protection, and heavy-duty work gloves when using this Riveter. Other people in the work area must also wear appropriate ANSI approved safety equipment.
- h. **Always wear hearing protection when using the tool.** Prolonged exposure to high intensity noise can contribute to hearing loss.

3) Tool Use and Care

- a. **Use clamps or other practical ways to secure and support the workpiece to a stable platform.** Holding the work by hand or against the body is unstable and can lead to loss of control.
- b. **Do not force the tool. Use the correct tool for the application.** The correct tool will do the job better and safer at the rate for which the tool is designed.
- c. **Do not use the tool if the trigger does not turn the tool on or off.** Any tool that cannot be controlled with the trigger is dangerous and must be repaired, by an authorised repair agent.
- d. **Disconnect the tool from the air source before making any adjustments, changing accessories, or storing the tool. Such preventative safety measures reduce the risk of starting the tool unintentionally.** Turn off and detach the air supply, safely discharge any residual air pressure, and release the throttle and/or turn the switch to its off position before leaving the work area.
- e. **Store idle tool out of the reach of children and do not allow persons unfamiliar with the tool or these instructions to operate the tool.** Tools are dangerous in the hands of untrained users.
- f. **Maintain the tool with care.** A properly maintained tool is easier to control.
- g. **Check for misalignment or binding of moving parts, breakage of parts, and any other condition that affects the tool's operation.** If damaged, have the tool serviced before using, at an authorised Kinchrome repair agent. Many accidents are caused by poorly maintained tools.
- h. **Use only accessories that are identified by the manufacturer for the specific tool model.** Use of an accessory not intended for use with the specific tool model, increases the risk of injury to persons.

4) Service

- a. **Tool service must be performed only by qualified repair personnel.**
- b. **When servicing a tool, use only identical replacement parts. Use only authorized parts.**
- c. **Use only the lubricants specified by the manufacturer.**

5) Additional Safety Warnings

- a. **The warnings and precautions discussed in this manual cannot cover all possible conditions and situations that may occur.** It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.
- b. **Only use with accessories rated to handle the forces exerted by this tool during operation.** Other accessories not designed for the forces generated may break and forcefully launch pieces.
- c. **Attach all accessories properly to the tool before connecting the air supply.** A loose accessory may detach or break during operation.
- d. **Use the right tool for the job.** Do not attempt to force a small tool or attachment to do the work of a larger industrial tool. There are certain applications for which this tool was designed. Do not modify this tool, and do not use this tool for a purpose for which it was not intended. Normal use of this product is likely to expose the user to dust and /or microscopic particles containing chemicals known to (the State of California) cause cancer, birth defects or other reproductive harm. Always wear appropriate safety equipment and clothing when using this product. Study, understand and follow all instructions provided with this product.
- e. **Anyone using vibrating tools regularly, or for an extended period should first be examined by a doctor and then have regular medical check-ups to ensure medical problems are not being caused or worsened from use.** Pregnant women or people who have impaired blood circulation to the hand, past hand injuries, nervous system disorders, diabetes, or Raynaud's Disease should not use this tool. If you feel any symptoms related to vibration (such as tingling, numbness, and white or blue fingers), immediately discontinue use and seek medical advice as soon as possible.
- f. **Do not smoke during use.** Nicotine reduces the blood supply to the hands and fingers, increasing the risk of vibration-related injury.
- g. **Wear suitable gloves to reduce the vibration effects on the user.**



WARNING! Some dust created by power sanding, sawing, grinding, drilling, and other construction activities, contains chemicals known to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- **Lead from lead-based paints**
- **Crystalline silica from bricks and cement or other masonry products**
- **Arsenic and chromium from chemically treated lumber**





Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

6) Additional Safety Instructions for Air Hydraulic Riveters

- a) **Stay within air pressure capacity.** Do not operate the Riveter above 90 psi.
- b) **Do not use the tool outside of the designed intent.**
- c) **Fire the Rivets into an appropriate work surface only.** This Riveter is designed for use on metal objects only, and is not suitable for soft surfaces.
- d) **Do not fire the Rivets too close to the edge of a workpiece.** They may split the workpiece and cause it to fly free, causing personal injury.
- e) **Transport the Riveter safely. Disconnect the air supply when moving the tool in the workplace.** Carry the tool by the handle and avoid contact with the Trigger.

7) Description of Symbols

The following symbols could be shown on the tool:

| | | | |
|--|---|---|---|
|  | Read the instruction manual before use. |  | Risk of Explosion |
|  | Wear Ear Protection |  | Wear Eye Protection |
| CFM | Cubic Feet per Minute flow | SCFM | Cubic Feet per Minute flow at standard conditions |
| PSI | Pounds per square inch of pressure | NPT | National pipe thread, tapered |
| Nm | Newton meters of force | BSP | British standard pipe |

8) Assembly

Connecting the Air Supply to the Air Hydraulic Riveter

1. Wrap teflon tape (not supplied) around the Nitto Style Fitting (11) approximately 4 to 5 times to ensure a leak free seal.
2. Screw in Nitto Style Fitting (11) to the Air Inlet (1) of the Air Hydraulic Riveter.
3. Using a 14mm spanner (not supplied) fasten the Nitto Style Fitting (11).
4. Pull back the female coupler on your air hose, and feed over the Nitto Style Fitting (11).
5. Release the female coupler on your air hose. You should now have a leak free, air supply to your tool.

Assembling the Frame Cap (6)

1. Secure the Frame Cap (6) Firmly to the Air Hydraulic Riveter by feeding the Frame Cap Nut (5) over the Frame Cap (6).
2. Continue by catching the thread of the Frame Cap Nut (5) to the Air Hydraulic Riveter and rotate clockwise. Ensure that the slot on the Frame Cap (6) is facing upward to avoid spilling used Rivet pins.

Changing Air Hydraulic Riveter Nose Pieces (3)

Note: Different size Nose Pieces require different Jaw assemblies. The supplied tools are for maintenance only. Please use a 17mm (for rear jaw case) & 19mm (for front jaw case) Spanners (not supplied) when loosening the jaw cases for the first time.

(For 6.4mm, 5.6mm, 4.8mm & 4.0mm Rivets use 13a, 13b & 13c)

(For 3.2mm, 2.4mm Rivets use 12a, 12b & 12c)

Note: Add anti-seize on thread of Rear Jaw Case (14).

1. Remove the nose piece with the supplied Riveter Nose Piece Spanner (9b) by rotating anticlockwise.
2. With the supplied Riveter Ring Spanner (9a) remove the frame head by rotating anticlockwise.
3. Using the supplied Jaw Spanner (10) to hold the groove of the Rear Jaw Case (14). Then use the Riveter Spanner (9c) to loosen the front Jaw Case (13a) by rotating anticlockwise.
4. Remove the Large Front Jaw Case (13a) which houses the Large Jaws (13b) and Large Jaw Pusher (13c).
5. Gather the Small Front Jaw Case (12a) and drop the Small Jaws (12b), followed by the Small Jaw Pusher (12c) into the Small Front Jaw Case (12a).
6. Thread the small Front Jaw Case (12a) to the Rear Jaw Case (14). Using the supplied Jaw Spanner (10) to hold the groove of the Rear Jaw Case (14). Then use the Riveter Spanner (9c) to tighten the front Jaw Case (13a) by rotating clockwise.

DO NOT OVERTIGHTEN.

Note: If the front Jaw Cases (12a or 13a) do not assemble correctly, then the Jaw Pusher (12c or 13c) has not aligned with the spring, remove and retry.

7. Reinstall the Frame Head (4) and desired Nose Piece (3) using the supplied tools.
8. Repeat above instructions when assembling Large Jaws (13a, b & c).

Air Hydraulic Riveter User Instructions

9) Before Starting

TO PREVENT SERIOUS INJURY FROM EXPLOSION:





Verify compressor is off before setup. Use only clean, dry, regulated, compressed air to power this tool. Do not use oxygen, carbon dioxide, combustible gases, or any other bottled gas as a power source for this tool.

1. It is recommended a filter, regulator with pressure gauge, oiler, in-line shut-off valve, and quick coupler be fitted for optimal operation, as shown on Figure A.
2. An in-line shut-off ball valve is an important safety device, it will shut-off the air supply even if the air hose is ruptured. The shut-off valve should be a ball valve because it can be closed quickly.

Note: If an automatic oiler system is not used, add a 4 to 5 drops of Kincrome Air Tool Oil to the air inlet before operation. Add a 1-2 more drops every hour of continual use.

3. Attach an air hose to the compressor's air outlet. Connect the air hose to the Nitto Style Fitting (11) of the tool. Other components, such as a quick connect fitting and quick connect coupler, will make operation more efficient, but are not required.



WARNING! Do not install a quick coupler directly on the tool. Couplers contains an air valve that will allow the air tool to retain pressure and inadvertently operate after the air supply is disconnected.

4. The air hose must be long enough to reach the work area and allow free movement while working. **Do not exceed 10 metres.**
5. Turn on the air compressor according to the manufacturer's directions and allow the tank to build up pressure until it cuts-off.
6. Adjust the air compressor's regulator so that the air output is at the tools recommended working pressure, the output must not exceed the tool's maximum air pressure at any time. Adjust the pressure gradually, while checking the air output gauge to set the optimal pressure range. **Do not exceed 90 PSI.**
7. Inspect all air connections for leaks. Repair any leaks.
8. If the tool is not being used, turn off and detach the air supply, safely discharge any residual air pressure, and release the Trigger (2) and/or turn the tools switch to its off position to prevent inadvertent operation.

10) Operation

| Aluminium Rivets Capacity | Steel Rivets Capacity | Stainless Rivets Capacity |
|---------------------------|-----------------------|---------------------------|
| 2.4mm (3/32") | 2.4mm (3/32") | 2.4mm (3/32") |
| 3.2mm (1/8") | 3.2mm (1/8") | 3.2mm (1/8") |
| 4.0mm (5/32") | 4.0mm (5/32") | 4.0mm (5/32") |
| 4.8mm (3/16") | 4.8mm (3/16") | 4.8mm (3/16") |
| 5.6mm (7/32") | 5.6mm (7/32") | - |
| 6.4mm (1/4") | 6.4mm (1/4") | - |

1. Ensure the Frame Cap (6) is secured to the Air Hydraulic Riveter.

Note: Ensure that the slot on the Frame Cap (6) is facing upwards to avoid spilling used Rivet pins.

2. Select the desired Nose Piece (3) you require for the size of rivet being used.
3. Using a drill (not supplied), drill into the material you wish to Rivet.

Note: When drilling rivet holes, use the same diameter drill bit as the outer diameter.

4. Attach an air hose to the Nitto Style Fitting (11) attached to the Air Hydraulic Riveter, covered in the assembly "Before Starting" section of this manual.

5. Turn on your compressor, and set the regulator between 70-90psi.

Caution: The Air Hydraulic Riveter should never exceed 90 PSI. Doing so may cause injury to person or damage to the tool.

6. Insert the shank of the Rivet through the Nose Piece (3) of the Air Hydraulic Riveter.

Caution: Be careful when loading Rivets, DO NOT press Trigger (2), Injury may occur!

7. Insert the rivet through the pre drilled hole in the work piece/material from step 3, and hold steady with your hand.
8. Hold the Air Hydraulic Riveter firmly against workpiece with both hands, and squeeze the Trigger (2) to activate the Riveter.
9. Release the Trigger (2) and remove the Air Hydraulic Riveter from the workpiece. The Rivet shank will shoot into the clear Frame Cap (6) & your Riveter will be fixed to your workpiece.
10. When you are finished using the Air Hydraulic Riveter, disconnect the tool from your air hose and purge any remaining air, by holding down the Trigger (2).

11) Cleaning, Maintenance, and Lubrication

Note: These procedures are in addition to the regular checks and maintenance explained as part of the regular operation of the air-operated tool.

Lubrication (Air Tool Oil)

1. Disconnect the tool from the air supply holding it so the Air Inlet (1) faces up.
2. Depress the Trigger (2) down and put 4 to 5 drops of Kinchrome air tool oil in the Air Inlet (1). Depressing the Trigger (2) helps circulate oil in the motor.
3. Reconnect the Air Hydraulic Riveter to the air supply.

To Prime The Riveter (Hydraulic Oil)



WARNING! Make sure the Air Hydraulic Riveter is disconnected from its air supply hose prior to performing any maintenance, service, or changing accessories.

1. Disconnect the tool from the air supply holding it so the Air Inlet (1) faces up.
2. Use the Riveter Ring Spanner (9a) to unscrew and remove the Lock Nut (8) located at the bottom of the Air Hydraulic Riveter.
3. Use a pair of pliers (not included) to remove the Piston Assembly from the Cylinder (7).
4. Clean inside of the Cylinder (7) and lubricate cover seal.
5. Hold the Cylinder (7) upside down, and pour in hydraulic oil such as K12400 Kinchrome Hydraulic Jack Oil (not included).

Note: The fill level should only reach the top of the Frame.

6. Insert the Piston Assembly back into the Cylinder (7).
7. Use the Riveter Ring Spanner (9a) to firmly screw the Lock Nut (8) back onto the Cylinder (7).

Storage

1. Avoid storing the Air Hydraulic Riveter in a location subject to high humidity. If the tool is left as it is used, the residual moisture inside the tool can cause rust. Before storing and after operation, oil the tool and run it for a short time.
2. Regular inspection should be carried out of the Air Hydraulic Riveter.




Please scan QR Code for 'How to Prime your Riveter' instruction video.

12) Warranty

Warranty given by Kincome Australia Pty Ltd of 3 Lakeview Drive, Caribbean Park, Scoresby, Victoria (Tel 1300 657 528). The applicable warranty period (24 months) commences on the date that the product is purchased. If this product has materials or workmanship defects (other than defects caused by abnormal or non warranted use) you can, at your cost, send the product to place of purchase, an authorised Kincome service agent or one of Kincomes addresses for repair or replacement. Your rights under this warranty are in addition to any other rights you have under the Australian Consumer Law or other applicable laws. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. For further details please visit www.kincrome.com.au or call us. Due to minor changes in design or manufacture, the product you purchase may sometimes differ from the one shown on the packaging.

IMPORTANT! If the tool fails to operate correctly, call customer service on 1800 657 528 for advice on the best resolution for your situation. If a resolution cannot be achieved over the phone please take the tool and all related accessories to an authorised service centre or place of purchase showing proof of purchase for assistance.

13) Parts Breakdown



| | Part No | Description | Qty |
|---|--------------|--------------------|-----|
| | K13271-1 | Nosepieces | 1 |
| • | K13271-1A | Nosepieces, 3/32" | 1 |
| • | K13271-1B | Nosepieces, 1/8" | 1 |
| • | K13271-1C | Nosepieces, 5/32" | 1 |
| • | K13271-1D | Nosepieces, 3/16" | 1 |
| • | K13271-1E | Nosepieces, 7/32" | 1 |
| • | K13271-1F | Nosepieces, 1/4" | 1 |
| • | K13271-06-1 | Jaw Case, Front | 1 |
| • | K13271-06-1A | Jaw Case, Front | 1 |
| • | K13271-06-2 | Jaw Case, Rear | 1 |
| • | K13271-07 | Jaw | 2 |
| • | K13271-07A | Jaw | 2 |
| • | K13271-08 | Jaw Pusher | 1 |
| • | K13271-08A | Jaw Pusher | 1 |
| • | K13271-09 | Case Washer Ring | 1 |
| • | K13271-10 | Spring, Jaw Pusher | 1 |
| • | K13271-11 | Frame Head | 1 |
| | K13271-12 | Lock Nut | 1 |
| | K13271-13 | Backup Ring | 2 |
| # | K13271-14 | O Ring | 4 |
| | K13271-15 | Frame | 1 |
| | K13271-16 | Piston Ass. | 1 |
| # | K13271-17 | O Ring | 1 |
| | K13271-18 | Backup Ring | 1 |
| | K13271-19 | Spring | 1 |
| | K13271-19-1 | Spring | 1 |
| | K13271-20 | Hanging Clip | 1 |
| # | K13271-20A | O Ring | 1 |
| | K13271-21 | Frame Cap | 1 |
| • | K13271-22 | Nut, Frame Cap | 1 |

| | Part No | Description | Qty |
|---|-------------|---------------------|-----|
| • | K13271-23 | Safety Cap | 1 |
| | K13271-24 | Spring Pin | 1 |
| | K13271-27 | Lock Nut, Frame | 1 |
| | K13271-28 | Rubber Cushion | 1 |
| | K13271-29 | Cylinder | 1 |
| | K13271-30-1 | Stem, Air Piston | 1 |
| | K13271-30-2 | Piston Ring | 1 |
| | K13271-30-3 | Lock Nut, Piston | 1 |
| # | K13271-31 | O Ring | 1 |
| # | K13271-32 | O Ring | 1 |
| | K13271-33 | Cap, Cylinder | 1 |
| • | K13271-35 | Jaw Spanner | 1 |
| • | K13271-36 | Riveter Spanner | 1 |
| | K13271-37 | Spring Pin, Trigger | 2 |
| | K13271-38 | Spring Pin | 1 |
| | K13271-39 | Trigger Rod | 1 |
| | K13271-40 | Trigger | 1 |
| | K13271-42 | Trigger Lever | 1 |
| | K13271-43 | Spring Pin | 1 |
| # | K13271-43A | O Ring | 1 |
| | K13271-44 | Pusher | 1 |
| # | K13271-44A | Spring, Pusher | 1 |
| # | K13271-45 | Valve | 1 |
| # | K13271-45A | Collar, Valve | 1 |
| # | K13271-45B | O Ring | 1 |
| # | K13271-46 | Spring, Valve | 1 |
| # | K13271-51 | O Ring | 1 |
| | K13271-52 | Cap, Valve | 1 |
| • | K13271-53 | O Ring Kit | 1 |

• Indicated stocked spare parts. We reserve the right to change spare parts at any time without notice.

Indicates contents included in K13271-53 O Ring Kit

KINCROME 
PROFESSIONAL QUALITY TOOLS

www.kincrome.com.au