

K13086 assembly:

- 1. Carefully remove contents from the packaging.
- 2. Select a firm, level surface on which to assemble the Teardown Table with Parts washer
- 3. Tools required (not supplied) 2 x 14mm Spanner, 1 x 13mm Spanner and 1 x Phillips screw driver

Packed Contents

Description	Qty	Description	Qty
Parts Washer	1	Oil Tub	1
Drain Table	1	Oil Tub Stop Bracket	1
Handle Frame	1	Bolts M14 x 65mm	4
End Frame	1	Bolts M14 x 45mm	8
Fixed Sliding Frame	1	Bolts M13 x 40mm	2
Parts washer support Leg	1	Flat Washers	24
Lower Shelf	1	Spring Washers	2
Locking Castors	2	Screws	2
Castors	3	Small Flat washer	2
		Nut	10

Know your product



Assembling Lower storage Section

1. Locate the Handle frame (4), End Frame (2) and the Lower Shelf (6).
2. Align the holes in the bottom of the Handle frame (4) and End Frame (2) with the 4 holes in the corners of the Lower Shelf (6).
3. Place flat washer onto bolt M14 x 45mm and insert Bolt through Handle frame (4) and Lower Shelf (6).
4. Place flat washer and nut onto end of bolt M14 x 45mm and hand tighten.
5. Repeat steps 3 and 4 for remaining holes in Lower Shelf (6).

Note: Do not fully tighten nuts at this time.

Attaching Fixed Sliding Frame

1. Locate the Fixed Sliding Frame (5) and Parts Washer support (9).
2. Sit the Fixed Sliding Frame (5) into the cross sections of the Handle frame (4) and on top of End Frame (2).
3. Ensure Sliding Frame Lock (11) is disengaged, gently extend out the Sliding Frame (10) extended position.
4. Align the holes of the fixed Sliding frame (5) with the holes in the Handle frame (4) and End Frame (2).
5. Place flat washer onto bolt M14 x 65mm and insert Bolt through Handle frame (4) and Fixed Sliding Frame (5).
6. Place flat washer onto bolt M14 x 65mm and insert bolt through end frame (2) and Fixed Sliding Frame (5).
7. Place flat washer and nut onto end of bolt M14 x 65mm and hand tighten.
8. Sit the Parts Washer support (9) on the underside of the Sliding Frame (10).
9. Insert the bolts M13 x 40mm and flat washer **through from the bottom of the bracket** of the Parts Washer support (9) and through the fixed Sliding Frame (10) holes.
Note: If the bolt is not inserted from the bottom of the bracket it limit on how far the parts washer can slide under the teardown table.
10. Place flat washer, spring washer and nut onto end of bolt M14 x 45mm and hand tighten.

Note: Do not fully tighten nuts at this time.

Attaching Drain Table

1. Locate the Drain Table (3).
2. Align the holes in the top of the Handle Frame (4) and End Frame (2) with the 4 holes in the corners of the Drain Table (3).
Note: Ensure the drain hole is located near the Handle Frame (4).
3. Place flat washer onto bolt M14 x 45mm and insert through Handle Frame (4) and Drain Table (3) and hand tighten.
4. Repeat steps 2 and 3 for remaining holes in End Frame (2).

Note: Do not fully tighten nuts at this time.

Attaching the Castors

1. Locate the two Locking Castors (7) and the three Castors (8).
2. Turn the Tear down table upside down on a piece of cardboard or old carpet.
3. Align the Locking Castors (7) with the Handle Frame (4) holes and tighten.
4. Using 2 Castors (8) screw into the bottom of the End Frame (2) holes.
5. Using 1 Castor (8) screw into the bottom of the Parts Washer Support (9) hole.
6. Tighten all castors.
7. Return the Teardown Table to the upright position.

Attaching the oil tray

1. Locate the Oil Tray (12) and Oil Tray Stop Bracket.
2. Align the holes of the Oil Tray Stop Bracket with the holes on the outside of the Drain Table (3).
3. Place the small flat washer on the screw and insert through the Oil Tray Stop Bracket into the Drain Table (3) and tighten.
4. Align the Oil Tray (12) with the oil tray supports located on the underside of the Drain Table (3) and gently slide into place.

Tightening all Nuts and Bolts

1. Ensure the Teardown table is correctly assembled as specified above.
2. Using 2 x 14mm Spanners, tighten all the Lower Shelf (6) bolts and nuts.
3. Using 2 x 14mm Spanners, tighten all the Sliding Frames (10) bolts and nuts.
4. Using 1 x 14mm Spanner, tighten all the Drain Table (3) bolts and nuts.
5. Using 1 x 13mm Spanner and 1 x 14mm Spanner tighten all the Parts Washer support (9) bolts and nuts.

Mounting the parts washer:

1. Ensure Sliding Frame Lock (11) is disengaged, gently extend out the Sliding Frame (10) extended position.
2. Place the Parts Washer (1) into the sliding frame.

Caution: Ensure the power cord does not get caught between the Parts Washer (1) and Sliding Frame (10) this may result in damage to the supply cord.