


K15035 parts list


Part No.	Code	Description
1	K15035-1	Up lift handle
2	K15035-2	Lower lift handle
3	K15035-3	Power socket
4	K15035-4	Top cover
5	K15035-5	Switch
6	K15035-6	Power cable
7	K15035-7	Platen power cord
8	K15035-8	Cable sleeve
9	K15035-9	PCB with Internal wiring
10	K15035-10	Isobar secure cap
11	K15035-11	NYLON cable ties
12	K15035-12	Round frame
13	K15035-13	Out of the wind baffle
14	K15035-14	spring for wind baffle
15	K15035-15	Motor cover
16	K15035-16	Rubber ring for motor
17	K15035-17	Motor-P
18	K15035-18	Motor gasket
19	K15035-19	Protect valve components
20	K15035-20	Spong for eliminate noise
21	K15035-21	Base for motor
22	K15035-22	Rubber ring for motor base
23	K15035-23	Float
24	K15035-24	Float basket
25	K15035-25	Float basket filters
26	K15035-26	Barrel
27	K15035-27	Suction Block
28	K15035-28	Rubber ring for Suction Block
29	K15035-29	Base
30	K15035-30	Castor
31	K15035-31	antistatic chain components
32	K15035-32	Dust bag
33	K15035-33	Metal telescopic tube
34	K15035-34	Floor nozzle with metal plate
35	K15035-35	Crevice nozzle
36	K15035-36	Dust brush
37	K15035-37	Suction hose 1.5m with two connector

K15035 Explosive Drawing

Head Parts



Accessory parts



Tank parts

