

TOOL TROLLEY 5 DRAWER K7795

Operation Manual

Caution: Take Safety Precautions When Using Your Toolbox



⚠ IMPORTANT:

THIS OPERATING MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. READ CAREFULLY AND UNDERSTAND ALL INFORMATION BEFORE OPERATING TOOL. SAVE THIS MANUAL FOR FUTURE USE.











Drawer Load Limit









Parts List









Trolley Handle x 1



16 x 12mm Bolts for Castors

TOOL TROLLEY SPECIFICATIONS

	Width	Depth	Height	
Overall	765mm	465mm	850mm	
Overall (w/out Castors)				
	765mm	465mm	690mm	
Top Section	670mm	455mm	15mm	
Drawers				
Shallow	565mm	395mm	60mm	
Deep	565mm	395mm	135mm	
Castor Size	125x50mm (5"x2") 2x Locking			
Total Weight	45.3kg		•	



Non-Locking Swivel Castors (2)



Locking Swivel Castors (2)



4 x 10mm Bolts for Handle



6 x Liners

Handle

TOOLS & ASSISTANCE NEEDED



2 People Lift



10mm Spanner or 5mm Hex Key



TOOL TROLLEY 5 DRAWER K7795

Assembly Instructions

1 Handle Installing

- Position the trolley side handle behind the holes on the trolley.
- Attach with (4) bolts and washers and tighten with an adjustable wrench.

Note: The side handle can be mounted to either side of the trolley.

2 Castor Installing (If applicable)

- Be sure the drawers are locked and lay the trolley on its side.
- Secure castors to the unit using the 12mm bolts provided
- Tighten with a 12mm spanner or 5mm hex key
- Repeat this process for the castors on the opposite of the trolley.
- Return the trolley to its upright position.

Caution: Do not over tighten the bolts.

Caution: Both locking castors must be fitted to front of trolley.

3 Removing the Drawers


- Fully extend the empty drawer.
- Push up the right grey release lever while pushing down the left grey release lever.
- Pull the drawer outward until it is released from the drawer slide.

4 Re-Inserting The Drawers

- Extend the drawer slides.
- Insert the brackets on each side of the drawer into the slots on the slides, being careful that they are properly positioned.
- Once properly inserted, completely close the drawer to set the slides in their proper positions.

MAINTENANCE

- Periodically tighten all hardware
- Periodically lubricate castors
- Lubricate the slides twice a year
- Lubricate the lock with graphite annually
- Use a damp Microfibre cloth to clean all surfaces





TOOL TROLLEY 5 DRAWER K7795

Replacement Parts



ITEM	PART NO.	DESCRIPTION	QUANTITY
1	K7888	Key Only (Specify Key Number) x1	1
2	K7787-1	Lock & Key	1
3	K7787-3	Trolley Handle	1
4	K7787-4	Ball Bearing Slides (Pair)	5
5	K7787-5	Drawer Grip (Large)	5
6	K7787-6	EVA Mat Pack 8 Piece	1

ITEM	PART NO.	DESCRIPTION	QUANTITY
7	K7787-7	Large Drawer (Shallow)	3
8	K7787-8	Large Drawer (Deep)	2
9	K7787-12	Castor Swivel X 1	2
10	K7787-10	Castor Swivel X 1 (Brake)	2
11	K7787-11	Castor Bolt Pack	1



National Head Office National Distribution and Showroom 3 Lakeview Dve, Caribbean Business Park Scoresby Victoria 3179 Australia ABN 41 007 185 006 Administration T +61 3 9730 7100 F + 61 3 9730 7199

E enquiries@kincrome.com.au W kincrome.com.au

Customer Service Centre T 1300 657 528 F 1300 556 005 Made to Kincrome Tools & Equipment Pty Ltd Global specifications and quality standards in China Kincrome UK Ltd PO Box 646 EASTLEIGH SO50

Australia & Global	UK & EU	
www.kincrome.com.au	www.kincrome.co.uk	
enquiries@kincrome.com.au	enquiries@kincrome.co.uk	