KINCROME LOK-ON

Repair Kit Contents:

- 1 Quick Release Gear
- 2 Backing Plate 3 Selector Mechanism
- 4 Pawl
- 5 Selector Mechanism
- 6 Retaining Pin
 7 2x Screws
 - 8 Retaining Spring
- 9 Selector Mechanism
- Spring

 Direction Switch

^{*}Repair Kit contains grease & TORX® key

KINCROME C LOKE-ON

LOK ON Ratchet Repair Kit

• Clean the inside of the

Instructions

 Use the hex key to remove the screws and disassemble the ratchet

To repair

- Insert direction switch.
 Insert larger retaining spring into the slot at base of the ratchet.
 - 3. Insert the larger retaining pin into the spring. The extruded end will fit inside the spring.
 - 4. Insert the smaller selector mechanism spring into the selector.

 5. Insert smaller retaining.
 - Insert smaller retaining pin into the spring of the selector mechanism. The extruded end will fit inside the spring.
 Insert the selector
 - Insert the selector mechanism into the ratchet head
 - 7. Selector and direction switch will connect

ratchet once removed

- together when inserted correctly.
- Insert the pawl on top of the selector mechanism.
- Apply grease to quick release gear and place
- into the ratchet head.

 10. Screw the backing plate back into place with the
- two provided screws.

 11. Test the ratchet gear and switch both move freely
- each way.

 12. Test the quick release button/function



SCAN FOR LOCATION FEATURES OR VISIT WEBSITE