

Thank you for purchasing a Kincrome product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY

1.1. GENERAL

- ✓ Ensure the worklight is fully charged before initial use.
- x **DO NOT** turn the worklight on when it is being charged.
- x **DO NOT** shine directly into your, other person's or animal's eyes.
- x **DO NOT** allow children to use the worklight.
- x **DO NOT** handle or move the worklight whilst it is being charged.
- x **DO NOT** use the worklight if you suspect that the battery or the worklight casing is damaged.
- x **DO NOT** leave battery in a discharged state, recharge battery immediately. Before storage, fully recharge the battery, subsequently recharge the battery at least once every six months of non-use.

1.2. ELECTRICAL SAFETY FOR USE OF CHARGER.

USE ONLY THE SUPPLIED CHARGER PLUG FOR CONNECTING Worklight TO THE POWER SUPPLY.

- **WARNING!** It is the user's responsibility to read, understand and comply with the following electrical instructions:

You must ensure the risk of electric shock is minimised by the installation of appropriate safety devices.

An RCCB (Residual Current Circuit Breaker) should be incorporated in the main distribution board. We also recommend that an RCD (Residual Current Device) is used with all electrical products, particularly portable equipment which is plugged into an electrical supply not protected by an RCCB.

You must also read and understand the following instructions concerning electrical safety:

If in any doubt about electrical safety, contact Kincrome customer service or a qualified electrician.

1.2.1. You must ensure that you:

- ✓ Inspect the charger plug, cable and connector for wear and damage to ensure items are safe before connecting to the mains power supply. If worn or damaged **DO NOT** use.

- ✓ **Important:** Check that the voltage marked on the charger plug is the same as the worklight.
- ✓ Uncoil the cable between charger and the worklight.
- x **DO NOT** pull the charger plug from the mains socket by the lead.
- **WARNING! DO NOT use any other type of charger with this product, other than the supplied mains or car charger. Failure to observe this warning could result in injury and or fire and will invalidate the warranty.**
- x **DO NOT** try to take the charger plug apart.
- x **DO NOT** use the charger plug to charge or power any other electrical item.
- x **DO NOT** get the charger wet, or use in wet, damp conditions (for indoor use only).

1.3. BATTERY SAFETY

- **WARNING! To reduce the risk of burns or fire:**
- x **DO NOT** attempt to open, disassemble, modify or service the battery pack.
- x **DO NOT** crush, puncture, short external contacts or dispose of in fire or water.
- x **DO NOT** expose to temperatures above 60°C (140°F).
- ✓ Replace only with the battery pack designated for this product.
- ✓ Recycle or dispose of used battery as stipulated by local legislation.
- ✓ If the electrolyte in the cells gets on your skin, thoroughly wash with soap and water. If it gets in your eyes, rinse thoroughly with cool water and seek immediate medical attention.

2. INTRODUCTION / SPECIFICATION

Innovative flexible shaft enables the light source to be positioned in any direction. The worklight houses a super bright, focusable, LED allowing the user to change between spot or flood beam. Features a flexible shaft, dimmer switch and super strong magnetic base allowing hands free operation. High quality 2200mAh Lithium-ion battery for longer life, no memory effect and a much slower discharge than traditional Ni-MH batteries. Supplied with micro USB charger.

Part No: K10208
 Battery: Li-ion 3.7Vd.c. 2200mAh
 LED Max Power:5W
 Lumen Output:390lm

Length:390mm
 Operating Time:2.5 hours (On brightest setting)
 Charging Time: 3.5 - 4hrs

3. CHARGING

□ IMPORTANT WARRANTY INFORMATION:

The battery fitted to this cordless tool is considered to be a consumable item and its ability to accept charge will reduce over time. We will warranty it against mechanical and electrical defect for a period of one year - this does not cover fair wear and tear. If the battery is not properly charged before first use, or regularly conditioned, its capacity will diminish. Under these circumstances we will not replace the battery even if it is less than one year old.

Note: Fully charge the worklight before first use.

Note: The Lithium battery does not suffer from memory effect and once fully charged may be stored for up to six months without another charge.

- 3.1. Connect the charger into the micro USB socket (Fig.2A) on the right side of the worklight. Plug into power supply and turn on, the charging LED (Fig.2B) on the worklight will light RED to show charging has commenced.

- 3.2. When the battery has fully charged the LED will turn BLUE.

4. OPERATION

- 4.1. Direct the worklight away from your eyes before switching on. Rotate the ON / OFF brightness Dial clockwise to increase light intensity/brightness; rotate the dial anti-clockwise to decrease the lights intensity/brightness. To turn the worklight off rotate the brightness dial anti-clockwise until a click noise is heard.
- 4.2. Mount the worklight by using the integral magnet located at the base of the light. While the light is mounted the worklight can be adjusted to the desired position by using the flexible shaft.
- 4.3. The focusable, LED on this worklight can be adjusted by rotating the focusable head anti-clockwise to achieve a spot beam, and clockwise to achieve a flood beam.




fig.1

Environmental Protection.

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycle centre and disposed of in a manner which is compatible with the environment.

WEEE Regulations

Dispose of this product at the end of its working life. When the product is no longer required, it must be disposed off in an environmentally protective way. Contact your local solid waste authority for recycling information.

Battery Removal

Remove the 6 screws on the back of the worklight. Remove the back casing, and disconnect the wiring to the circuit board. Remove the two battery mounting screws. Dispose of battery according to local government guidelines.



Warranty given by Kincrome Australia Pty Ltd of 3 Lakeview Drive, Caribbean Park, Scoresby, Victoria (Tel 1300 657 528). If this product has materials or workmanship defects (other than defects caused by abnormal or non warranted use) you can, at your cost, send the product to place of purchase, an authorised Kincrome service agent or one of Kincromes addresses for repair or replacement. Your rights under this warranty are in addition to any other rights you have under the Australian Consumer Law or other applicable laws. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. For further details please visit www.kincrome.com.au or call us.

addresses for repair or replacement. Your rights under this warranty are in addition to any other rights you have under the Australian Consumer Law or other applicable laws. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. For further details please visit www.kincrome.com.au or call us.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 1300 657 528 and leave your full name and address, including postcode.




fig.2



NATIONAL DISTRIBUTION & SHOWROOM
 3 Lakeview Drive, Caribbean Business Park
 Scoresby, Vic. 3179, Australia, P.O Box 135,
 Ferntree Gully, Vic. 3156, Australia

CUSTOMER SERVICE CENTRE

☎ Phone: 1300 657 528

☎ Fax: 1300 556 005

✉ Email: enquiries@kincrome.com.au

🌐 Internet: www.kincrome.com.au